

# KOMPLETE KONTROL A-SERIES

## BROWSER CONTROL

- Select Browser fields 
- Search Browser tags and Presets 
- Select Browser tags 
- Load selected Preset in Results list 
- Clear Browser Filters 
- Set Preset as Favorite in Results list 
- Sort by Favorites in Results list 
- Toggle between User Content and Factory Content 

## PLUG-IN CONTROL

- Control Instrument and Plug-in parameters 
- Navigate Plug-in chain 
- Add FX Plug-in on empty Plug-in slot 
- Move selected FX Plug-in left or right in Plug-in chain 
- Select previous/next Preset 
- Navigate parameter pages 

## PLUG-IN CONTROL

- Bypass selected Plug-in in Plug-in chain 
- Remove selected Plug-in from Plug-in chain 

## TRACK CONTROL

- Select previous/next track 
- Select previous/next region 
- Mute/unmute selected Track 
- Solo/unsolo selected Track 
- Adjust Track volume 
- Adjust panorama for selected Track 

## EDIT CONTROL

- Undo action 
- Redo action 
- Quantize to grid value 
- Toggle automation between Read mode and Touch mode 

# Logic/GarageBand

## TRANSPORT CONTROL

- Start playback 
- Restart playback 
- Punch out while recording 
- Start recording 
- Punch in while playback is running 
- Enable/disable count-in 
- Stop playback/recording at current position 
- Relocate playhead position to song start when stopped 
- Scroll playhead position 
- Enable/disable loop mode 
- Move loop by its own length 
- Enable/disable metronome 
- Tap tempo 

## BROWSER CONTROL

Select Browser fields



Search Browser tags and Presets



Select Browser tags



Load selected Preset in Results list



Clear Browser Filters



Set Preset as Favorite in Results list



Sort by Favorites in Results list



Toggle between User Content and Factory Content



## PLUG-IN CONTROL

Control Instrument and Plug-in parameters



Navigate Plug-in chain



Add FX Plug-in on empty Plug-in slot



Move selected FX Plug-in left or right in Plug-in chain



Select previous/next Preset



Navigate parameter pages



## PLUG-IN CONTROL

Bypass selected Plug-in in Plug-in chain



Remove selected Plug-in from Plug-in chain



## TRACK CONTROL

Select Tracks



Select Clip Slot in Track



Start/stop selected Clip



Mute/unmute selected Track



Solo/unsolo selected Track



## EDIT CONTROL

Undo action




Redo action



Quantize to grid value



Toggle automation between Read mode and Touch mode



## TRANSPORT CONTROL

Start playback



Start Clip recording



Start Arranger recording



Scroll playhead position



Stop playback/recording at current position



Relocate playhead position to song start when stopped



Enable/disable loop mode



Enable/disable metronome



Tap tempo



## BROWSER CONTROL

- Select Browser fields
- Search Browser tags and Presets
- Select Browser tags
- Load selected Preset in Results list
- Clear Browser Filters
- Set Preset as Favorite in Results list
- Sort by Favorites in Results list
- Toggle between User Content and Factory Content

## PLUG-IN CONTROL

- Control Instrument and Plug-in parameters
- Navigate Plug-in chain
- Add FX Plug-in on empty Plug-in slot
- Move selected FX Plug-in left or right in Plug-in chain
- Select previous/next Preset
- Navigate parameter pages

## PLUG-IN CONTROL

- Bypass selected Plug-in in Plug-in chain
- Remove selected Plug-in from Plug-in chain

## IDEAS CONTROL

- Select Group
- Select Scene
- Create new Scene
- Select Pattern
- Create new Pattern

## TRACK CONTROL

- Select Group
- Select another Sound of that Group
- Create new Group

## TRANSPORT CONTROL

- Start/stop playback
- Restart playback at the beginning of the Loop Range
- Enable/disable recording
- Record with count-in
- Stop playback/recording
- Enable/disable metronome
- Adjust tempo
- Enable/disable loop mode

## EDIT CONTROL

- Undo action
- Redo action
- Quantize to grid value
- Enable/disable automation
- Enable/disable Scale engine
- Edit Scale engine parameters
- Enable/disable Arpeggiator
- Edit Arpeggiator parameters